


Operating Manual



BULK AIR™ PM **Negative Pressure Monitor**

Certification

Bulk Air™ Limited certifies that this product met the published specifications at the time of shipment. Bulk Air™ Limited further certifies that its calibration measurements are traceable to the National Institute of Standards and Technology (NIST).

Warranty

This Bulk Air™ Limited product is warranted against defects in materials and workmanship for a period of one (1) year from the date of shipment.

Service

For warranty service or repair, this product must be returned to a Bulk Air™ authorised service facility. Contact an authorised distributor before returning this product for repair.

Information in this document is subject to change without notice.

Copyright © Bulk Air™ Limited 2013. All rights reserved.

Bulk Air Limited
Unit 5 The Sunhill Centre
Fleets Lane, Rylstone, Skipton,
North Yorkshire. BD23 6NA.

www.bulkair.co.uk

Manufactured in U.K.

Safety and Preparation for Use

CAREFULLY READ THE IMPORTANT SAFETY INSTRUCTIONS AND NOTES INCLUDED IN THIS SECTION BEFORE USING THE BULK AIR™ PM NEGATIVE PRESSURE MONITOR AND ITS ACCESSORIES. SAFETY PAYS!

Within this section, the word 'product' specifically refers to the Bulk Air™ PM negative pressure monitor and any of its accessories.

The intention of this section is to collect, in a single place, the most common risks associated to the installation, operation and maintenance of this product. The instructions are also repeated, with additional information, at the appropriate points throughout this manual.

This product has been designed with user-safety as a priority and has been proven to show reasonably safe operation provided it is installed, operated and serviced in strict accordance with all the safety instructions included in its manual.

Safety Instructions and Warnings


- SAFETY PAYS! Safety instructions must be strictly followed during all stages of installation, operation and service of this product. Failure to comply with these precautions and warnings violates the safety standards expected of users of this product.
- If you have any doubts about how to use this product safely, contact your authorised distributor at the address listed in this manual.
- Retain these safety and operating instructions for future reference.
- Identify and adhere to all warnings posted on the product.
- Failure to comply with these instructions may result in serious personal injury, including death, as well as significant property damage.
- It is the installer's responsibility to ensure the safe operation of ventilation and filtration equipment. Carefully check installation, pressure test points and alarm set points before operation.
- Provide for fail-safe operation wherever an equipment malfunction could lead to a hazardous situation.

Electrical Shock Risks

<p style="text-align: center;">THE MOST COMMON RISK ASSOCIATED WITH THE OPERATION OF ELECTRICAL PRODUCTS IS ELECTRICAL SHOCK.</p>
--

- Dangerous voltages capable of causing injury and death are present during the operation of this product. Do not remove the covers while the unit is plugged into a live outlet.
- Always operate the unit in its proper horizontal orientation. Do not operate the unit on its side as foreign objects or liquids may enter through the printer slot, creating an unsafe condition.
- Do not use this product if it has unauthorised modifications. Unauthorised modifications may result in fire, electric shock and other hazards.
- Do not install substitute parts or perform any unauthorised modifications to this product.
- This product must only be used with a mains supply fitted with a 3A fuse.
- The product has a detachable, three-wire power cord for connection to the power source. The exposed metal parts of the product are connected to the power cord ground to prevent against electrical shock. Always use a power cord which has a proper connected protective ground. Consult with an electrician if necessary.
- GFCI (Ground Failure Circuit Interrupter) protected outlets are often available in working environments, particularly in proximity to water sources. GFCI's are generally regarded as an important defence against electrocution. GFCI's must also be tested regularly to verify their functionality. Always consult an electrician when in doubt.
- Do not use accessories not recommended in this manual as they may be hazardous.
- Always turn off the power to the product before connecting any cables to the product.
- To reduce the risk of fire and electrocution do not expose this product to rain or moisture. Be careful not to spill liquid of any kind onto or into the product.
- Only use high quality cables and connectors that properly shield all high voltage terminals.
- Do not push objects of any kind into this product through openings as they may come in contact with dangerous voltage points or short out parts that could result in a fire or electric shock.
- Operation of this product with line voltages other than those accepted by the power supply can cause damage to the product and injury to personnel.

Introduction



The Bulk Air™ PM (Pressure Monitor) is the latest in pressure monitoring technology. It uses the latest in thermally compensated ASIC digital pressure sensors to achieve a highly stable and accurate pressure measurement down to 1Pa (1/10,000th of an atmosphere). Its' rotationally moulded case combined with polycarbonate bulkheads makes a very tough yet stylish product. The 5.7 Inch full-colour TFT display provides crystal clear presentation of the pressure status whilst a thermal printer provides a hard copy of all data. Additional effort has been invested to ensure simple and future-proof PC connectivity; a USB 2.0 connection makes it easy to drag pressure data off the product or upgrade the software in the field.

Ultimately the Bulk Air™ PM has been designed to be as simple and reliable as possible in order to provide the user with years of useful service.

Features:

- Large 5.7" colour display for ease of use and clarity of pressure results.
- Simple and quick user interface.
- Tough, impact resistant custom case.
- In-built thermal printer for on-site hard-copies of pressure results.
- Highly accurate digital pressure sensor with good long-term stability.
- USB connector to simplify downloading pressure results.
- Easy software upgrade for future-proof operation.
- Battery back-up so unit continues to work during loss of mains power.
- GSM/GPRS capabilities for SMS alerts.
- Configurable alarm outputs for sounder/strobe and auxiliary mains switch.

Front Panel Overview

WARNING!

Read the entire **Safety and Preparation for Use** section of this manual before using the Bulk Air™ PM negative pressure monitor.




Figure 1 - Bulk Air™ PM Front View

- 1) 5.7 Inch full-colour display – Clear results and user interface with a wider viewing angle than normal displays. A 4mm thick polycarbonate protector makes the display almost indestructible.
- 2) Thermal printer – On-site hard copy of results for every minute of every hour.
- 3) Carry handle / support legs – Makes the product easy to carry and when in use the product sits at an angle to improve screen visibility.
- 4) Paper feed button – Feeds paper out of printer and, if held down during power-up, will perform a test print.
- 5) Printer opening lever – Makes changing printer paper VERY simple.
- 6) Power On/Off button – Also used to cancel menu changes and silence alarms.
- 7) OK Button – Implements menu changes.
- 8) Down button – Used to navigate menu and decrement settings.
- 9) Up button – Used to navigate menu and increment settings.

Rear Panel Overview

WARNING!
 Read the entire **Safety and Preparation for Use** section of this manual before using the Bulk Air™ PM negative pressure monitor.




Figure 2 Bulk Air™ PM Rear View

- 1) Pressure Channel 1 – Simple push-on/pull-off pipe fittings.
- 2) Alarm output port – Connects to a series of auxiliary power switches and alarms.
- 3) USB connector. For transferring data between the product and user PC and upgrading software.
- 4) Power inlet socket – With fuse and spare fuse draw.
- 5) Rubber Feet – Ensures the product does not move during use.
- 6) Distributor plate – clearly identifies the product distributor.
- 7) SIM and SD Card cover plate – easily removed to change SIM or SD Card.
- 8) Pressure Channel 2 – Optional extra for monitoring a second pressure system.

Un-Packing the Bulk Air™ PM

Before unpacking the Bulk Air™ PM, please ensure the packaging does not have any signs of crush or impact damage. If there is visible damage to the packaging, please contact your local distributor.

Always open the packaging with care; do not use a knife to cut the packaging open as this may cause damage to the content.

Safely store the Bulk Air™ PM packaging for future use such as when transporting or storing the Bulk Air™ PM.

Once open, the Bulk Air™ PM packaging should contain the following parts:-

- Outer carton
- Front protection packaging
- Rear protection packaging
- Bulk Air PM unit
- Accessories packaging
- Mains cable with European plug
- Pressure tubing (2 x 5 meter lengths)
- USB Cable (USB A to mini B cable)

If any of the above items are not present in your packaging, double check your packaging then contact your local distributor.

Getting Started

WARNING!

Read the entire Safety and Preparation for Use section of this manual before using the Bulk Air™ PM negative pressure monitor.

- Ensure the Bulk Air™ PM is in good visible condition with no damage to the front or rear of the unit. If the Bulk Air™ PM appears to be damaged, contact your authorised distributor.
- Place the Bulk Air™ PM on a flat and stable surface where the front screen can be clearly seen and the buttons can be easily accessed by the user.

WARNING!

The Bulk Air™ PM negative pressure monitor must only be used OUTSIDE the contamination area to avoid the product being exposed to contamination.

- The product should be positioned so it is near to a mains supply and the point of work where the pressure is to be measured. This is to prevent long runs of tubes and cables which could pose a trip hazard and compromise the contamination containment area.
- Plug the mains power cable into the mains inlet socket at the rear of the unit (see *Rear Panel Overview*). Before connect the plug end of the mains cable into a mains outlet socket, ensure the mains cable is not damaged, crushed or showing signs of wear.
- Finally connect the pressure inlet pipes to pressure **CHANNEL 1** at the rear of the unit. It is recommended to use two pipes for pressure measurement. The pipe connected to the **NEGATIVE (-)** inlet port at the rear of the unit must be fitted to the negative pressure zone to be monitored. The pipe connected to the **POSITIVE (+)** inlet port at rear of the unit must be positioned vented to an area representative of the air pressure outside the negative pressure zone. It is not recommended to position the **POSITIVE (+)** inlet tube near windows, doors, fan-heaters or anything that could cause un-representative localised pressure variations.

Powering Up

To power-up the Bulk Air™ PM press and hold the **POWER BUTTON** (see *Front Panel Overview*) on the front of the unit until the self-test screen appears.

It should be noted that the firmware version number is displayed at the top of the self-test screen. It may be useful to know this when considering upgrading the firmware.



Figure 3 - Self-test screen

During self-test the Bulk Air™ PM tests its' hardware to ensure it is responding correctly. It tests the following:

- Printer
- Real-time clock
- SD Card
- SIM Card

The appearance of a tick next to each of these icons demonstrates the hardware is functioning correctly. If a cross appears next to any of the hardware icons refer to the trouble-shooting section of this manual for possible solutions.

If the self-test reports no problems the Bulk Air™ PM advances to the next screen automatically. If a problem is reported the self-test screen remains displayed until the user presses the **OK BUTTON**.

The next screen displays the next service date and the Bulk Air™ PM serial number.



Figure 4 - Service Date and Serial Number Screen

It is important to have the product serviced at regular intervals to ensure correct product operation. Contact you local distributor to arrange a product service.

The service screen will display for five (5) seconds before automatically advancing to the next screen.

The next screen is the distributor logo screen; this is displayed for five (5) seconds before the system goes to the main results screen.

Main Results Screen




Figure 5 - Main Results Screen

The main screen presents the pressure data in a clear graph, showing the last 60 minutes of recorded pressures. Each bar of the graph represents the lowest pressure difference measured during that minute. The colour of each pressure bar will change depending on the alarm status. The main results screen is composed of the following:-

- 1) Current differential pressure reading in Pascals (Pa). This value is updated every second and will display both positive and negative differential pressures, however only positive differential pressures will be displayed on the graph.
- 2) High pressure alarm point. This point does not move; the graph is re-scaled to fit. Differential pressures above the high alarm level are not displayed above the top of the graph.
- 3) Low pressure alarm point. This point will change position depending on the low alarm set point; it is scaled between the high alarm and the zero pressure point.
- 4) Time axis. This shows the time at which the corresponding pressure occurred. It scrolls every minute and displays the time at 15 minute intervals.
- 5) Battery back-up level (showing fully charged). The number of bars displayed indicates the present charge capacity of the battery back-up.
- 6) Mains power supply connected. If the mains power supply is lost this icon changes.
- 7) GSM signal strength (showing fully charged). The number of bars displayed indicates the GSM signal quality.

Menu Overview

Pressing the **UP BUTTON** or **DOWN BUTTN** from the main results screen will access the menu screens.




Figure 6 - Menu Password Screen

Before a user can access the menu screen the product requires a password to be entered. The password consists of a four (4) digit number. The default password for the product is '0000'. Each digit can be changed in-turn by using the **UP BUTTON** and **DOWN BUTTON** to increment and decrement the number respectively, pressing the **OK BUTTON** advances to the next password digit.

Following the successful entry of the password the product will display the first menu option screen. If the password is entered in-correctly or the **POWER BUTTON** is pressed the product will return to the main results screen.

Once in the menu system the **POWER BUTTON** can be used at any point to exit the menu, back to the main results screen without modifying the last menu setting. If no buttons are pressed for a period of 10 seconds the product will return back to the main results screen without modifying the last menu setting.

The **UP BUTTON** and **DOWN BUTTON** are used to scroll through the menu options and the **OK BUTTON** is used to select the menu option.

The selected menu option setting can be changed using the **UP BUTTON** and **DOWN BUTTON**. Pressing the **OK BUTTON** will implement the change and return to the main menu.

A full description of the menu options can be found in the *Menu Descriptions* section.

Menu Descriptions

Menu Icon	Description
	<p>High Alarm – Changes the high differential pressure alarm level. If the differential pressure increases above the high alarm level the product will alarm. The auxiliary mains switch will be turned off.</p>
	<p>Low Alarm – Changes the low differential pressure alarm level. If the differential pressure decreases below the low alarm level the product will alarm. The auxiliary mains switch will be turned on.</p>
	<p>Enable/Disable Printer – Selecting this menu option will toggle between enabling and disabling the printer. If the printer is enabled it will instantly print the pressure graph and summary data, this will then be repeated every 60 minutes.</p>
	<p>Displays the product serial number. This menu option is for information only and cannot be changed. It is important to ensure the serial number matches the serial number on the back of the product.</p>
	<p>System Time – This menu option enables the system time to be set. The time format uses the 24-hour convention 'hh:mm'. Due to country variations the system does not adjust for day light/summer time saving.</p>
	<p>System Date – This menu option enables the system date to be set. The date format used is 'dd/mm/yy'. If an incorrect date is entered (such as 30/02/13) the date reverts to its' previous setting.</p>
	<p>System Language – This menu option enables the system language to be changed.</p>

Alarms




Figure 7 - Alarm Activation

The alarm system of the product can be divided into three systems; differential pressure warning alarms, auxiliary mains switch alarm and product status alarms. The operation of these alarms is described in more detail below:-

1. High Differential Pressure Alarm Setting – Whilst the pressure is above this alarm level the product will alarm. This will also activate an external alarm, if connected to the product.
2. Low Differential Pressure Alarm Setting – Whilst the pressure is below this alarm level the product will alarm. This will also activate an external alarm, if connected to the product.
3. If the pressure is below the Low Differential Pressure Alarm Setting the auxiliary mains switch will be activated to operate a secondary air filtration system.
4. Once activated the auxiliary mains switch will remain active until the pressure rises above the High Differential Pressure Alarm Setting, at which point it will de-activate.
5. If the pressure falls below the Low Differential Pressure Alarm Level the auxiliary mains switch will activate until such time as the pressure rises above the High Differential Pressure Alarm Level again (see 4).

Printer

The Bulk Air™ PM uses the latest in embedded thermal printer which is very easy to load with new paper rolls.

To fit new paper rolls to the printer do the following:-



Figure 8 - Opening the Printer

Pull down the small lever on the right of the printer. This will cause the printer draw to open.



Figure 9 - Inserting Paper Roll

Once the printer draw is fully open; fit the new thermal paper roll so the paper comes from the top of the roll, with the print side facing the buttons, as shown above.

Finally, close the printer draw by gently pushing it shut. Once fully shut the lever on the right of the printer will also close.

Configuration Software

The Bulk Air™ PM is designed to be very easy to operate using the in-built menu system. However some more advanced features can be accessed using the simple configuration software which resides on the SD Card. The configuration software can be used on any Windows™ operating system and should be run from the Bulk Air PM by connecting it to a PC.

To run the Windows™ configuration software do the following:-

- Ensure the Bulk Air™ PM is turned off.
- Connect the Bulk Air™ PM to a desktop PC using a mini-USB cable.
- Turn the Bulk Air™ PM on. The unit will power up as normal but instead of displaying the main pressure screen it will show the USB connected screen.




Figure 10 - USB Screen

- The PC will show it has detected and configured the connection with the Bulk Air™ PM. Depending on the computer and operating system the computer may need to be re-booted.




Figure 11 - USB Device Found

- The Bulk Air™ PM appears as a removable flash-drive to the desktop PC and can be seen by viewing the available drives; clicking on My Computer in Windows™.




Figure 12 - Bulk Air™ PM Drive

- To view the files on the Bulk Air™ PM, double click on the Bulk Air™ PM drive.




Figure 13 - Bulk Air™ PM SD Card Files

- Double click on the Bulk Air™ PM application to run the configuration software.




Figure 14 - Bulk Air™ PM Settings Editor Application

- The Windows™ program will automatically load the Bulk Air™ PM previous settings, which can then be easily modified:-

Language – Enables the selection of language to be used for the Windows™ program and Bulk Air™ PM menu.

High Pressure alarm – Changes the high pressure difference alarm level.

Low Pressure alarm – Change the low pressure difference alarm level.

Job Description – Edit the description reference for the present job.

SMS Number 1 to 3 – Enter a cellular phone number to receive warning SMS text messages.

Globe button – Opens an internet browser with at the Bulk Air™ PM web page to access the latest Bulk Air™ PM firmware and user manual.

Folder button – Opens a folder showing saved pressure data stored on the Bulk Air™ PM.




Figure 15 - Bulk Air™ PM Saving Settings

- Once all settings are completed, close the program. Before the program closes it will ask if the settings should be saved. Clicking on YES will save the settings to the Bulk Air™ PM SD Card.




Figure 16 - Safely Removing Bulk Air PM USB

- Once the file has finished copying, ALWAYS safely disconnect the Bulk Air™ PM from the operating system to ensure the operating system has completed the copying task.
- Finally, turn the Bulk Air™ PM off. The next time the Bulk Air™ PM is turned on; it will load the new settings.

WARNING!

ALWAYS ensure the Bulk Air™ PM is safely removed from the Operating System before disconnecting the USB, failure to do so may result in damaged or corrupt SD card.

Installing SIM card

The Bulk Air™ PM is capable of sending up to three (3) warning SMS messages to remotely alert users of problems. In order to use this facility the Bulk Air™ PM requires a registered SIM card to be fitted in the back of the unit:-

WARNING!

ALWAYS ensure the Bulk Air™ PM is disconnected from the mains power supply and turned OFF before removing the back panel.

- First remove the SD card cover plate. This is done by removing the four (4) posi-drive screws securing the plate.



Figure 17 - SD Cover Plate

- Insert the pre-registered SIM card into the SIM card holder next to the SD card holder. Gently push the SIM card fully in.




Figure 18 - Inserting the SIM Card

- Once inserted; fit the SD cover plate using the four (4) posi-drive screws to secure the plate in place.



Figure 19 - SIM Card Fitted in Place

- To enable the warning SMS alerts the user will need to enter mobile phone numbers using the Configuration software. See the Configuration software section for more information.

IMPORTANT!

Ensure the SIM card does not have a PIN number enabled. Fit the SIM card into a spare mobile phone and using the phone menu DISABLE the PIN number.

Upgrading Software

The Bulk Air™ PM is designed to be very easy to upgrade in the field. This helps to ensure users are able to take advantage of the latest firmware and the useful features this brings. To ensure you are using the latest firmware, contact your local Bulk Air distributor.

To upgrade the Bulk Air™ PM firmware do the following:-

- Ensure the Bulk Air™ PM is turned off.
- Connect the Bulk Air™ PM to a desktop PC using a mini-USB cable.
- Turn the Bulk Air™ PM on. The unit will power up as normal but instead of displaying the main pressure screen it will show the USB connected screen.




Figure 20 - USB Connected Screen

- The desktop PC will show it has detected and configured the connection with the Bulk Air™ PM. Depending on the computer and operating system the computer may need to be re-booted



Figure 21 - Bulk Air™ PM USB Detected

- The Bulk Air™ PM appears as a removable flash-drive to the desktop PC and can be seen by viewing the available drives; clicking on My Computer in Windows™.




Figure 22 Bulk Air™ PM Flash Drive

- Simply drag and drop the firmware file onto the Bulk Air™ PM drive; this will copy the firmware file onto the Bulk Air™ PM.




Figure 23 - Copying files to Bulk Air™ PM

- Once the file has finished copying, ALWAYS safely disconnect the Bulk Air™ PM from the operating system to ensure the operating system has completed the copying task.




Figure 24 - Safely Removing Bulk Air™ PM USB

- Finally, turn the Bulk Air™ PM off. The new firmware is now on the Bulk Air™ PM SD card. The next time the Bulk Air™ PM is turned on; it will detect the new firmware and complete the upgrading process.
- The final upgrading process is indicated by a percentage bar displayed on the Bulk Air™ PM screen. This upgrading can take a few minutes. Once complete the unit will continue to power up and operate normally.

WARNING!

ALWAYS ensure the Bulk Air™ PM is safely removed from the Operating System before disconnecting the USB, failure to do so may result in damaged or corrupt SD card.

Product Specifications

Dimensions	200mm (h) X 300mm (w) X 300mm (d)
Weight	4kg
Power	90 to 264 VAC, 47 to 63 Hz, 125W
Working Temperature	5°C to +50°C
Storage Temperature	-20°C to +60°C
Working Humidity	20% to 80% RH non-condensing
Storage Humidity	10% to 90% RH non-condensing
Ingress Protection	IP54 Excluding power connector
Printer Type	Thermal direct line printing
Printer Paper Width	57mm
Printer Paper Roll Diameter	39mm
Printer Resolution	8 dots/mm (384 dots/line)
Display Size	5.7" (145mm)
Display Resolution	320 x 240 at 256 colours
Battery Back-Up	6 Hours
Data Storage Capacity	14 years of results based on 1Gb SD card
PC Connection	USB 1.0/USB 2.0 Mass Storage class
Measurement Pressure	±100Pa
Proof Pressure	±25,000Pa
Burst Pressure	±50,000Pa
Accuracy	±1Pa
Long Term Drift (1 Year)	±1Pa
In-Built Sounder	>95dB
Sounder Alarm Output	12VDC @ 500mA
Strobe Alarm Output	12VDC @ 500mA
NPU Control Output	12VDC @ 500mA
User Alarms	1 x High alarm, 1 x low alarm
Communications	Quad-Band GSM/GPRS
Field Up-gradable	Yes from SD Card

SD Card Filing Structure

The Bulk Air™ PM stores logged pressure data and loads settings from the SD Card installed in the back of the product. The files are stored in specific location, below is an example of where the Bulk Air™ PM stores the files.




Figure 25 - Bulk Air PM SD Card Filing Structure

EC Declaration of Conformity

In accordance with EN ISO 17050-1:2004

We **Bulk Air™ Limited**
of **Unit 5 The Sunhill Centre, Fleets Lane,
Rylstone, Skipton, North Yorkshire. BD23 6NA.**

In accordance with the following Directive(s):

- 2006/95/EC** **The Low Voltage Directive**
- 2004/108/EC** **The Electromagnetic Compatibility Directive**

hereby declare that:

Equipment **Negative Pressure Monitor**
Model Number **Bulk Air™ PM**

is in conformity with the applicable requirements of the following documents

Ref. No.	Title	Edition/date
EN 60204-1	Safety of machinery. Electrical equipment of machines. General requirements.	2006
BS EN 61000-6-1	Electromagnetic compatibility (EMC). Generic standards. Immunity for residential, commercial and light-industrial environments.	2001
BS EN 61000-6-3	Electromagnetic compatibility (EMC). Generic standards. Emission standard for residential, commercial and light-industrial environments.	2001

I hereby declare that the equipment named above has been designed to comply with the relevant sections of the above referenced specifications. The unit complies with all applicable Essential Requirements of the Directives.

Signed:



Name: **Geoffrey Swales**
Position: **Managing Director**
Done at: **Rylstone, Skipton**
On: **11th March 2013**

